Pitch line

Rise

90°

Span

Set out right angled triangle accurately to given dimensions

Add top edge of rafter parallel to pitch line

Add bottom edge of rafter parallel to top.

Add ridge and eaves details according to Location on drawing

Extend lines from plumb cut, birdsmouth and eaves.

Transfer the marks from the drawing to the wood.

Cut the rafter.

Setting out and marking the COMMON RAFTER.